These instructions are for your safety. Please read through them thoroughhJ before use and retain them for future reference.

Remove all packaging materials and check that the unit is not damaged before use. Decide on an appropriate location for you, product (see siting instructions below).

INSTALLATION

- Remove all packaging and carefully read instructions.
- Slide off outer casing on front of unit exposing batterv compartment. Lift off batterv cover and insert 2xAA NIMH rechargeable batteries replace both covers.
- Thread the Jet-Sprav unit onto the top of the sensor housing and tighten carefullv bv hand to avoid leaks (do not over tighten).
- For high flower beds, or to dater large, target pests, thread the stand-pipe extension onto the bottom of the sensor housing. Otherwise,



connect the sensor housing directly to the stake unit, ensuring it is tightened to avoid leaks (do not over tighten).

- Carefully push the stake into the ground in the desired location taking care not to apply direct pressure to the sensor unit housing. In hard ground, make a hole using a splke or fork before pushing the stake into the ground to avoid domage to the unit.
- Ensure the sensor unit is level, pointing in the direction of the area vou wish to protect, and that there is no foliage or obstructions in front of the PR sensor.

Siting Instructions

- This product is suitable for OUTDOOR USE ONLY.
- Connect garden hose to the unit but do not turn on.
- To test the PIR sensor, turn the dial (on back of unit) fully clockwise to position 9 and wave hand in front of sensor. The valve will open and click, then close again five seconds later.
- Set the sensitivity of the PIR sensor by turning the dial at the back of unit O is off and 9 will sense movement approximately 10 metres in front of the PIR sensor.
- Check the coverage area by walking in front of the PIR sensor until vou hear the openIng click. Adjust as above to increase or decrease size of protected zone.
- The Jet-Sprav Repeller's coverage area is arc-shaped. Set the width of this arc by sliding the two green tab extensions left and right. The wire clip moves between the two tab extensions when the Jet-Sprav Repeller is activated. The unit automatically switches direction when the wire clip hits a tab.
- Turn on the water supply and walk in front of the PIR sensor to test. Repeat steps 3 - 6 to adjust the coverage area as required.



Effective

Detects and repais foxes, herons, cats, squirrels and other nuisance animais In wInerable garden areas.

Easy Set-up


Uses batterv power and a standard quick-fit hose connection in any garden area.

Optional Helght

Stand *pipe* extension for high flower beds *or* larger target species.

Adjustable Area

Oto 10 metre PIR sensitivity enables variable coverage area up to 100 square metres.



WARNINGS

- This product is suitable for OUTDOOR USE ONLV.
- This product is intended for use as an animal deterrent only not to be handled by children.
- An adult must carry out battery replacement and installation.
- Do not dispose of batteries in a fire, batteries may explode or leak.
- Do not short-circuit the battery terminais.
- Do not mix new and used batteries.
- Do not recharge non-rechargeable batteries.
- Do not allow any part to corne in contact with heat or a direct flame.
- Only the recommended batteries should be used.
- If any part of the unit is damaged you should stop using it immediately.
- Do not operate this product in the packaging.

CARE AND MAINTENANCE

- Turn the unit off whenever pets are at play in the protected zone, *or* when gardening or, when other human activity is likely to trigger the unit.
- Do not immerse the unit in water or other liquids
- Do not tamper with the unit's internal components.
- From time to time use a damp cloth to wipe the PIR lens clean.
- Do not use alcohol, benzene or point thinners